



High precision automotive spare parts
German benchmark technology

**new at LASO:
repair kit for drivebelt**

with ContiTech® belts, pulleys, belt tensioning
damper and tensioning lever

LASO-no.: 9558 0512 S

consisting of VW kit:

~ (VW 059 198 119 B), ~ (VW 059 198 119 A),
~ (VW 059 198 119)

and in addition of damper and lever:

~ (VW 059 109 479 B) and ~ (VW 059 109 487 C)

