



High precision automotive spare parts  
German benchmark technology

**new at LASO:**

**driving device – 9805 0102**

**New technical design with tapered roller bearings!  
Made in Germany by LASO in-house!**

~ Renault 74 20 838 388

~ Volvo 20838388, ~ Volvo 8193986,

~ Volvo 20816480, ~ Volvo 20744444,

~ Volvo 20511839, ~ Volvo 20441702,

~ Volvo 3165996, ~ Volvo 85013115

